

TurBiScat PM 40

Operating Manual



1 Imprint

Consideration of applicable standards and guidelines

The content of this document has been compiled in accordance with applicable **standards** and **directives** and the **state of the art**.

The manufacturer accepts no liability for damage due to:

- Non-compliance with the instruction manual
- Non-intended use
- Use of untrained staff
- Unauthorised modifications

Copyright provisions (Copyright®)

- This document was written by Sigrist-Photometer AG. The copyright® is held by Sigrist-Photometer AG.
- Copying, modifying or translating the contents or passing it on to third parties is only permitted with the agreement of Sigrist-Photometer AG.
- The form (output medium) of this documentation is subject to the company Sigrist-Photometer AG.

Manufacturer

Sigrist-Photometer AG

Hofurlistrasse 1
CH-6373 Ennetbürgen. Switzerland
Phone +41 (0)41 624 54 54

www.sigrist.com
info@sigrist.com

Table of contents

1	Imprint	2
2	About this document	6
2.1	Purpose of the instruction manual	6
2.2	Storage of the instruction manual	6
2.3	Target group	6
2.4	Conformity	6
2.5	Representation conventions	7
3	Your Safety	8
3.1	Intended use	8
3.2	Restrictions on use	8
3.3	Foreseeable misuse	8
3.4	Warnings	8
3.5	Residual risks	9
4	Device data	10
4.1	General view	10
4.1.1	TurBiScat PM 40 with display	10
4.1.2	TurBiScat PM 40 with SiDis AD 40	10
4.2	Nameplate	11
4.3	Scope of supply and accessory parts	11
5	Mounting	12
5.1	General information on mounting	12
5.2	Mounting position of the photometer	12
5.3	Fitting in VARINLINE® connector	12
5.4	Mounting SiDis AD 40	13
5.4.1	Wall mounting	13
5.4.2	Rotate mounting plate	13
6	Electrical installation	14
6.1	Determine communication module	14
6.2	Photometer connection	14
6.2.1	EG_IO	14
6.2.2	EG_PoE	16
6.2.3	EG_Profibus	16
6.2.4	EG_Profinet	17
6.3	Connecting the TurBiScat PM 40 with SICON	17
7	Operation	19
7.1	Display	19
7.2	SIGRIST-Webinterface	19
8	Commissioning	20
9	Settings	22
9.1	Displays on the photometer	22
9.2	Sigrist-Webinterface	23

9.2.1	Homepage	23
9.2.2	First steps	23
9.3	Simple configuration mode	24
9.3.1	Menu: Configuration	24
9.3.2	Menu: Simulation	26
9.3.3	Menu: Recalibration	27
9.3.4	Menu: History	27
9.3.5	Menu: System info	28
9.4	Advanced configuration mode	29
9.4.1	Menu: IO module EG_IO	29
9.4.2	Menu: IO module EG_PoE	31
9.4.3	Menu: IO module EG_Profibus	31
9.4.4	Menu: IO module EG_Profinet	32
9.4.5	Menu: WLAN	32
9.4.6	Menu Configuration	33
9.4.7	Menu: Display	33
9.4.8	Menu: Simulation	34
9.4.9	Menu: Recalibration	34
9.4.10	Menu: Sensor check	34
9.4.11	Menu: Logger	34
9.4.12	Menu: System	35
9.4.13	Menu: Meas. Channels	36
9.4.14	Menu: Math. Channels	37
9.4.15	Menu: Measuring info	37
9.4.16	Menu: History	38
9.4.17	Menu: System info	38
9.5	Logger diagram	38
9.6	Field bus	39
9.6.1	General requirements	39
9.6.2	Fault codes	39
9.6.3	Modbus RTU/TCP	39
9.6.4	Profibus-DP	41
9.6.5	Profinet-IO	41
9.6.6	Profibus-DP/Profinet-IO data	41
10	Servicing	43
10.1	Maintenance schedule	43
10.2	Replace desiccant	43
10.3	Cleaning	44
10.3.1	Clean sensor head	44
10.4	Calibration check	44
10.4.1	Overview of control unit	44
10.4.2	Cleaning the control unit	45
10.4.3	Carry out calibration check with control unit	45
10.5	Replace seals (VARINLINE® connection)	47
10.6	Spare parts	47
11	Troubleshooting	48
11.1	Isolate faults	48
11.2	Warning/(Prio) error messages	49
11.3	Warning messages	49
11.4	Fault messages	50
11.5	Prio fault messages	51

12 Specification sheet.....	52
12.1 TurBiScat PM 40	52
12.2 General.....	53
12.3 SiDis AD 40	54
12.4 Communication modules	54
13 Returns.....	55
14 Decommissioning/storage	56
15 Disposal	57

2 About this document

2.1 Purpose of the instruction manual

This instruction manual is intended to ensure the safe, proper and efficient use of the device. It contains the relevant information for safety, design, function, commissioning, operation, maintenance and disposal over the entire product life cycle.

Failure to comply with the instruction manual and the safety instructions may result in hazards and restrictions for:

- life and limb of the operating staff
- the system and material assets
- the reliable, trouble-free operation of the unit.

NOTE



Non-compliance with the instruction manual

Sigrist-Photometer AG accepts no liability for damage resulting from non-compliance with the operating instructions.

2.2 Storage of the instruction manual

The instruction manual is an integral part of the unit. It must be available to staff at all times.

2.3 Target group

Qualified staff

This document is intended for trained staff who are familiar with the local conditions.

2.4 Conformity

EU Declaration of Conformity



The device complies with the requirements for affixing the CE marking within the European Union (EU).

EU Declaration of Conformity TurBiScat PM 40

<https://www.sigrist.com/Dokument/?revid=16855>



EU Declaration of Conformity SiDis AD 40

<https://www.sigrist.com/Dokument/?revid=16864>



UKCA Declaration of Conformity



The device meets the requirements for affixing the UKCA marking within the United Kingdom.

UKCA Declaration of Conformity TurBiScat PM 40

<https://www.sigrist.com/Dokument/?revid=16854>



UKCA Declaration of Conformity SiDis AD 40

<https://www.sigrist.com/Dokument/?revid=16863>



2.5 Representation conventions

Symbols and text markings

This document contains various symbols and text markings.

Symbol	Name	Function
	Tip	Provides the reader with supporting information about the action currently described.
	Action	The triangle marks actions that must be performed in the appropriate order.
	Reaction	The white triangle marks the reaction to an action.
Representation conventions  7]	Cross-reference	Cross-references are used to refer to a page within the document. They are linked and can be executed in electronic form with a mouse click.
	Function editable	The menu function currently described is editable.
	Function read-only	The menu function currently described is read-only.
«Menu»	Menu	«Menus» or «functions» included in the software.
[Ok]	Button	Buttons used to navigate the Sigrist web interface.
<i>Device-specific</i>	Placeholder	Serves as a placeholder for an unspecified, changing term.

3 Your Safety

3.1 Intended use

The TurBiScat PM 40 and its peripherals are designed for turbidity measurement in liquids. Possible applications can be found in the following areas:

Areas of application

- Food and beverage industry

Applications

- Filtration monitoring in beverages such as beer, fruit juices, spirits
- Monitoring of centrifuges, separators, whirlpools in the beverage industry
- Turbidity measurement in oils, sugar solutions, foodstuffs

3.2 Restrictions on use

DANGER

Use in hazardous areas

The use of this device in potentially explosive atmospheres may cause explosions.



- ▶ The device must not be operated in potentially explosive areas or rooms.
- ▶ Additional components, such as control units or tablets, must not be operated in potentially explosive areas or rooms.
- ▶ The device must not be used for explosive sample substances.

3.3 Foreseeable misuse

DANGER

Hazards in case of foreseeable misuse

Incorrect use of the device can result in injuries to persons, process-related consequential damage and damage to the device and its periphery. In the following cases, the manufacturer cannot guarantee the protection of persons and the device and therefore does not accept any liability:



- ▶ The device is used outside the area of application.
- ▶ The device is not installed, set up or transported properly.
- ▶ The device is not installed and operated according to the operating instructions.
- ▶ The device is operated with accessories that are not expressly recommended by Sigrist-Photometer AG.
- ▶ Improper modifications are made to the device.
- ▶ The device is operated outside the specifications.
- ▶ The device is exposed to shocks, vibrations or other mechanical forces.

3.4 Warnings

The warnings are four-tiered: Danger, warning, caution, notice. They include: Nature of the hazard, possible consequences and measures to avert it.

Signal word

Meaning

DANGER	Signal word to indicate a hazard with high risk, which will directly result in death or serious physical injury.
WARNING	Signal word to indicate a hazard with medium risk, which can possibly result in death or serious physical injury.
CAUTION	Signal word to indicate a low-risk hazard that may result in minor or moderate bodily injury.
NOTE	Signal word for a potentially harmful situation in which the equipment or an object in its vicinity may be damaged.

3.5 Residual risks

The device has been built in accordance with the applicable standards and the recognised safety rules and corresponds to the state of the art. However, according to the risk assessment of the applied safety standard DIN EN 61010-1, injuries to persons, damage to the device or material damage to the infrastructure cannot be completely ruled out during use.

Danger from electricity



The device is operated with 24 VDC (PoE 48 VDC). If a power supply unit (100 ... 240 VAC) is also used, there is a risk of electric shock with fatal consequences if open cables are touched.

- ▶ Do not operate the device unless it has been properly installed and repaired.
- ▶ Only operate the device if all cables are undamaged.
- ▶ Never operate the power supply with the case removed or open.

Danger due to incorrect supply voltage



An incorrect supply voltage may damage the device and render it inoperable.

- ▶ The device may only be connected to voltage sources that match the nameplate.

Danger due to high pressures



During maintenance, repairs or adjustments to a pressurised pipeline, injury to persons, damage to the device or material damage to the infrastructure may occur.

- ▶ Be sure to drain the process line before removing the photometer.
- ▶ Always consult the operating instructions for maintenance, repairs or adjustments to pipelines.

Danger due to liquids



Escaping medium at the device or at the connections can lead to flooding of the room or material damage to the infrastructure.

- ▶ Check for leaks regularly.
- Ingress of moisture and condensation on electronic components can cause damage.
- ▶ Carry out maintenance work as described in the operating instructions.
 - ▶ Avoid accumulation of condensation on optical and electrical surfaces.

Risk of leakage at the process line



Leakage at the process line can lead to escaping medium. Contact with the medium can lead to burns, chemical burns or poisoning with a fatal outcome.

- ▶ Ensure that the device meets the requirements of the medium.
- ▶ Take protective measures and wear protective clothing.

Danger from use of aggressive chemicals for cleaning



The use of aggressive cleaning agents can damage the device.

- ▶ Do not use aggressive chemicals or solvents for cleaning.
- ▶ If the device has nevertheless come into contact with aggressive chemicals, check it immediately for damage.

Faulty measured value display during operation



Incorrect display of measurements cannot be completely ruled out.

- ▶ Apply the access code to prevent parameters from being changed by unauthorised persons.
- ▶ Carry out maintenance work as described in the operating instructions.

Unauthorised access to the device



Unauthorised access by third parties may lead to changes in the configuration and incorrect measurements therefore cannot be ruled out.

- ▶ Ensure that the operator takes safety precautions to prevent unauthorised access.

4 Device data

4.1 General view


4.1.1 TurBiScat PM 40 with display



TurBiScat PM 40 with display

- (1) TurBiScat PM 40
- (3) WLAN input device
- (5) Touchscreen
- (2) WLAN connection
- (4) Operating device or control system

4.1.2 TurBiScat PM 40 with SiDis AD 40




TurBiScat PM 40 with SiDis AD 40

- (1) TurBiScat PM 40 without display
- (3) WLAN connection
- (5) Operating device or control system
- (2) SiDis AD 40
- (4) WLAN input device
- (6) Touchscreen

4.2 Nameplate

The nameplates are placed on the TurbiScat PM 40 (1) and SiDis AD 40 (2). They contain:

- Device type
- Type ext.: Device name
- PN: Article number
- SN: Serial number
- U: Service voltage
- P: Power
- DOM: Production date
- Conformity information
- Warning notice
- Manufacturer



4.3 Scope of supply and accessory parts



The scope of delivery can be found in the sales documents.

The accessory parts are available online.

<https://www.sigrist.com/Turbidity-Meters-Analyzers-Liquid/TurBiScat-PM-40/Parts>



5 Mounting

5.1 General information on mounting

Use detailed dimension drawings for mounting the photometer and control unit.

- Distance of photometer to interfering light sources > 2 m.
- Prevent the formation of gas bubbles on the sensor head by using a suitable installation position.
- Distance of photometer from cable bends and elements that change the cross-section > 1 m.
- Ensure that the installation position is self-draining.

5.2 Mounting position of the photometer



For vertical fitting, the plugs must point downwards. For horizontal fitting, the plugs should be on the left side.


In process line

Fitting position (A) and (B): Permitted

Fitting position (C): Permissible under the following conditions:

- Medium temperature:
 - -10 ... +80°C
 - 120° C max. 2 h
 - 150° C max. 1 h
- Continuous medium flow at > 2 bar pressure

Fitting position (D): Impermissible




EHEDG-compliant

Fitting positions (A) and (C): Permitted


Fitting position (B) and (D): Impermissible

VARINLINE® housing (spherical housing): EHEDG-compliant



5.3 Fitting in VARINLINE® connector


- ▶ Mount photometer (1) including seal (7) with clamp ring (3) on VARINLINE® connector.
- ▶ Make sure that the marking (2) points in the flow direction.
- ▶ Mount blanking plate (5), including seal (6) with clamp ring (4) on VARINLINE® connector.



5.4 Mounting SiDis AD 40

5.4.1 Wall mounting


- Mount SiDis AD 40 on the wall with two screws (1) according to the dimension drawing.



5.4.2 Rotate mounting plate

If necessary, the mounting plate can be rotated by 90° as follows:

- Loosen four screws (2).
- Turn the mounting plate (1) in the desired position.
- Fasten with four screws (2).



6 Electrical installation

DANGER

Danger due to improper connection of the operating voltage.


Improper connection of the electrical service voltage can be life-threatening. The system can also be damaged in the process.



- ▶ Connection must be carried out by a specialist in accordance with local regulations.
- ▶ Install a disconnecting device near the power supply to disconnect the device from the mains. The disconnecting device should be easily accessible and labelled.
- ▶ Use shielded cables and connect the cable shield to earth.

6.1 Determine communication module

The integrated communication module can be seen on the nameplate [▶ 11](#). The following codes **(1)** are possible: IO = EG_IO | PE = EG_PoE | PB = EG_Profibus | PN = EG_Profinet




6.2 Photometer connection

A distinction is made between two variants:

- Photometer **(PM)** with integrated display and connections ¹⁾
- Photometer **(PM)** without display connected to SiDis AD 40 ²⁾

6.2.1 EG_IO



(A) M12 8-pin plug-in connector A coded

Function	Designation	Plug-in connector pin no.	Colour
GND	GND	1	white
24 V	24 V	2	brown

RS485 Modbus RTU

Configurable with or without 120 Ω termination.

Function	Designation	Plug-in connector pin no.	Colour
A	IO1	7	blue
B	IO2	5	grey

Digital input 5-28 VDC

Function	Designation	Plug-in connector pin no.	Colour
----------	-------------	---------------------------	--------


IN 1	IO1	7	blue
IN 2	IO2	5	grey

Digital output "High Side Switch" max. 20 mA

Function	Designation	Plug-in connector pin no.	Colour
Out 1	IO1	7	blue
Out 2	IO2	5	grey
Out 3	IO3	6	pink
Out 4	IO4	4	Yellow


Power output terminal 0/4 ... 20 max. 700 Ω

Function	Designation	Plug-in connector pin no.	Colour
Current 1	IO3	6	Pink
Current 2	IO4	4	Yellow
Current 3	IO5	8	red
Current 4	IO6	3	green

Wiring diagram EG_IO

6.2.2 EG_PoE


- PoE (802.3af, class 0)
- Cable characteristics: Cat. 6, STP, AWG 24/7, TIA-568A. Fast Ethernet 100Base_T supported
- Available web services: Web server, Modbus TCP



(A) M12 4-pin socket D coded

Function	Plug-in connector pin no.
TX+	1
RX+	2
TX-	3
RX-	4

6.2.3 EG_Profibus



(A) M12 5-pin socket B Coded


Function	Plug pin no.
5V	1
PB_A	2
GND	3
PB_B	4

(B) M12 5-pin plug B Coded

Function	Plug pin no.
5V	1
PB_A	2
GND	3
PB_B	4

(C) M12 8-pole plug A Coded

Function	Plug pin no.	Colour
GND	1	white
24V	2	brown

6.2.4 EG_Profinet

(A) port 2 M12 4-pin socket D coded / **(B)** port 1


Function	Plug-in connector pin no.
TX+	1
RX+	2
TX-	3
RX-	4

(C) M12 8-pin plug-in connector A coded

Function	Plug-in connector pin no.	Colour
GND	1	white
24 V	2	brown

6.3 Connecting the TurBiScat PM 40 with SICON

To connect the TurBiScat PM 40 with the SICON, simply plug in the A-coded M12 wire female end into the Tur-BiScat. Inside the SICON you can connect the wires according to this table:



Function	Colour	Terminal SICON
GND	White	8
24V DC	Brown	9
A	Blue	10
B	Grey	11

The SICON (M) manual is available online. **NOTICE!**
Some functions in the manual only refer to the SICON M.



The SICON (M) connection diagram is available online.




7 Operation

The most important operating data can be viewed on the local display. Parametrisation is carried out via a WLAN-capable device

7.1 Display


Navigation is carried out using swipe gestures. Navigation aids are located at the bottom (1) and left (2). If there is no activity, the display switches to the default display after one minute. The content depends on the device configuration. Example:



7.2 SIGRIST-Webinterface

The content depends on the device configuration. Example:

- (1) Menu settings
- (2) Status
- (3) Current measured values
- (4) 7 day logger diagram
- (5) LED temperature
- (6) Sensor internal temperature
- (7) Sensor humidity
- (8) Status inputs
- (9) Status outputs




8 Commissioning

- ▶ Ensure correct mounting and electrical installation.
- ▶ Establish service voltage.
 - ▷ Start screen appears.

Rotate display if necessary

Rotating the display is only possible in the start-up display.

- ▶ Briefly touch rotation symbol **(1)**.
 - ▷ The display rotates by 90°.
- ▶ Repeat until the display is in the correct position.



Activating the WLAN

- ▶ Navigate to «WLAN connection».
- ▶ Swipe down.
 - ▷ WLAN is activated.



Connect mobile device

NOTICE!

No VPN connection must be active on the mobile device.

- ▶ Connect the mobile device to the WLAN with the QR code.
- ▶ Confirm the warning "No Internet connection" with **[OK]**.
 - ▷ The mobile device is connected.

Alternative:

- ▶ Connect the mobile device to the WLAN.
- ▶ Select the displayed SSID.
- ▶ Enter the displayed access code.
- ▶ Confirm the warning "No Internet connection" with **[OK]**.
 - ▷ The mobile device is connected.



Sigrist-Webinterface Open

- ▶ Access URL with QR code.

Alternative:


- ▶ Open browser (e.g. Chrome, Safari).
- ▶ Enter the displayed URL (192.168.10.1).
 - ▷ Login screen appears.



Log in to SIGRIST-Webinterface

- ▶ Log in without password.


Recommendation: Secure access to the SIGRIST-Webinterface with a password.



9 Settings

9.1 Displays on the photometer

Navigation is carried out using swipe gestures. Navigation aids are located at the bottom (1) and left (2). If there is no activity, the display switches to the standard display after one minute.



Displays on the photometer

Status displays

If the display on the photometer is set to status display, these status displays are shown. The default display can be set in the menu [▶ 33](#).

(1) Device in measuring mode, no malfunction.

(2) Warning

(3) Error




9.2 Sigrist-Webinterface

9.2.1 Homepage


After logging in, the Sigrist-Webinterface appears in measuring mode. The content depends on the device configuration. Example:

- (1) Open menu
- (2) Start menu
- (3) Settings for the photometer Simple [▶ 29]/Advanced [▶ 29] configuration mode
- (4) Log in/log out
- (5) Change language
- (6) Open logger diagram



9.2.2 First steps

- ▶ Open menu (1).
- ▶ Select «language» (2).
- ▶ Select [settings] (3).
 - ▷ The Simple Configuration Mode (4) appears(Advanced Configuration Mode (5))



9.3 Simple configuration mode

If necessary, change the configuration mode.

9.3.1 Menu: Configuration

	Parameter	Values	Default value
	«WLAN region» Select the region in which the device is operated. WLAN channels 1...11 are used in the USA. Channels 1...13 are used in other countries	List of regions	USA
	«System time» Apply the date and time.	Adjust...	
	«Image rotation» Orientation of the display.	0°, 90°, 180°, 270°	0°
	«Access code» Enter access code (numbers only). Used to protect against unauthorised access.	...	0
	«Designation» Enter the name of the measurement point identification in the Sigrist-Webinterface (max. 13 characters).	...	

9.3.1.1 Communication module EG_IO

Only available with communication module EG_IO.

	Parameter	Values	Default value
	«Function» Select parametrisation templates: Connection to SICON/SiDis: • IO 1: RS485 A • IO 2: RS485 B • IO 3...6 Inactive 0/4...20mA Outputs_ ▶ 25: • IO 1: Digital output - warning, error, priority • IO 2: Digital output - Inactive • IO 3: Current output channel 1 • IO 4: Current output channel 2 • IO 5: Current output channel 3 • IO 6: Current output channel 4 *) Further settings can be made in the Advanced parametrisation mode ▶ 29 . Connection to SICON/SiDis	Connection to SICON/SiDis 0/4...20 mA output *) Own settings	
	«Integration» Set the integration time for all measuring channels.	0...60000 s	10

All other parameters can be set on the SICON/SiDis or mobile device.

0/4...20 mA outputs

	Parameter	Values	Default value
	«Integration» Set the integration time for all measuring channels.	0...60000 s	10
	«0/4mA...20 mA» Set current range for measured value output.	0...20 mA/4...20 mA	4...20 mA
	«For service» Set the measured value output in service mode.	0 Value/Last value	Last value
	«Max. value» Set the highest possible current value at the measured value output. Current values above 20.0 mA correspond to more than 100% measured value of the current measuring range.	20...21 mA	21 mA
	«If fault» Set the current value to be output in the event of an error (only relevant for current range 4...20 mA).	0...4 mA	2 mA

Power output 1...n

	Parameter	Values	Default value
	«Source n» List of available sources. To reduce power supply, set power output terminals that are not needed to Inactive .	K1...Kn/Math 1...2/humidity/inactive	Cn
	«Measuring range n» Set from...to values of the measuring range.	-5000...1E9	Log: 0...3/Lin: 0...100

9.3.1.2 Communication module EG_PoE

Only available with EG_PoE communication module.

	Parameter	Values	Default value
	«DHCP» Automatic assignment of IP addresses. - DHCP On: Assigned IP address, gateway address and subnet mask are displayed. - DHCP Off: Enter IP address, gateway address, subnet mask and DNS server manually.	On/Off	On
	«IP address» Enter IP address.	XXX.XXX.XXX.XXX	192.254.1.1
	«Gateway addr.» Enter gateway address.	XXX.XXX.XXX.XXX	192.255.255.0
	«Sub-net mask» Enter subnet mask.	XXX.XXX.XXX.XXX	255.255.255.0

Parameter	Values	Default value
-----------	--------	---------------



«DNS server» Enter DNS server address. Appears if DHCP is set to Off .	XXX.XXX.XXX.XXX	0.0.0.0
--	-----------------	---------

9.3.1.3 Communication Module EG_Profinet

Only available with EG_Profinet communication module.

Parameter	Values	Default value
-----------	--------	---------------



«Station name» Enter the station name.		
---	--	--



«DHCP» Automatic assignment of IP addresses.	On/Off	On
---	--------	----

- DHCP On: Assigned IP address, gateway address and subnet mask are displayed.
- DHCP Off: Enter IP address, gateway address, subnet mask and DNS server manually.



«IP address» Enter IP address.	XXX.XXX.XXX.XXX	169.254.1.1
-----------------------------------	-----------------	-------------



«Gateway addr.» Enter gateway address.	XXX.XXX.XXX.XXX	169.254.1.0
---	-----------------	-------------



«Sub-net mask» Enter subnet mask.	XXX.XXX.XXX.XXX	255.255.255.0
--------------------------------------	-----------------	---------------



«DNS server» Enter DNS server address. Appears if DHCP is set to Off .	XXX.XXX.XXX.XXX	0.0.0.0
--	-----------------	---------



«Profinet transparent mode» • On: SIGRIST web server and Modbus TCP can be accessed via Profinet connection. • Off: Web server of gateway module (HMS) is accessible.	On/Off	On
---	--------	----

NOTICE!
Automatically set to "On" after device startup.

9.3.1.4 Communication module EG_Profibus

Only available with communication module EG_Profibus.

Parameter	Values	Default value
-----------	--------	---------------



«Slave no.» Enter slave number.	1 ... 126	1
------------------------------------	-----------	---

9.3.2 Menu: Simulation

Parameter	Values	Default value
-----------	--------	---------------



«Measuring value mode» Simulate measuring value at outputs. Each measuring value has its own multiplication factor to the basic simulation value (basic simulation value: Static = 1, Dynamic 1...2). With Simu value , an individual basic value can be specified.	Off/Static/Dynamic/Simu value	Off
---	-------------------------------	-----

	Parameter	Values	Default value
	«Simu value » If the Simu value function is set in the Measured value mode menu, the value specified here is applied as the basic simulation value.	...	1000
	«Fault mode» Simulate fault messages at the digital interfaces.	Off/List of errors	Off
	«Power output terminals» Specific values output at power output terminals.	Off/0...20 mA	Off
	«Outputs» Output specific states at digital outputs.	Off/All Off/All On/1...n On	Off
	«Light source» Manually switch the light source on or off for test purposes or to isolate faults (1 = LED turbidity, 2 = LED colour (optional)).	Off, 1, 2, 3	Off

9.3.3 Menu: Recalibration

Submenu: Recalibration K1...Kn

	Parameter	Values	Default value
	«Actual value» Current measured value.	<i>Current measured value</i>	-
	«Adjustment» Triggers the adjustment. Calculates a new correction factor from the actual and nominal values.	Trigger...	-
	«Act.corr» Specifies the current correction factor, which corrects the deviation from the factory calibration.	0,500...2000	1,000

9.3.4 Menu: History

History\ Fault

	Parameter	Values	Default value
	«Fault» View recorded warnings, faults, prio faults and information.	-	-

History\ Adjustment

	Parameter	Values	Default value
	«Adjustment» View chronologically recorded adjustment values.	-	-

9.3.5 Menu: System info

	Parameter	Values	Default value
	«Device type» View the device type.	Device name	
	«Serial number» View the serial number. This number is important when contacting customer service.	Device-specific	
	«Operating hrs.» View the operating hours since initial commissioning at the factory.	xxx	
	«Version Main» Software version of the main controller.	-	
	«Version Sensor» Software version of the sensor controller.	-	
	«Version Comm» Software version of the communication controller.	-	
	«Version IO» Software version EG_IO, for devices with EG_IO.	-	
	«Version Web» Software version of the interface for the Sigrist-Webinterface.	-	
	«Update firmware» Check online: With an Internet connection, it is possible to check whether new software is available. A valid DNS server address must be available in the communication module. Select file: Select new firmware. Upload & update: Upload firmware to sensor.	[Check online] [Select file...] [Upload & update]	
	«Reset to factory settings» Restore factory settings.	[Load...]	
	«Support information» Generate zip file with current data and configuration values for support. Generation takes approx. 30 seconds.	[Download]	

System info/Save & restore

	Parameter	Values	Default value
	«Backup» Save parameterization to measuring device. Enter a description according to the software text for identification.	[Create]	

Parameter	Values	Default value
 «Restore» Select one of the displayed configurations: Restore: Load selected version. NOTICE! The current configuration is overwritten and cannot be restored. Download: Download selected configuration. Delete: Delete selected configuration.	[Restore...] [Download...] [Delete...]	
 «Restore challenge» Individual code for loading the factory configuration.	xxxx	

9.4 Advanced configuration mode

If necessary, change the configuration mode.

9.4.1 Menu: IO module EG_IO

Only available with communication module EG_IO.

IO configuration\ IO 1...6

The assigned functions vary depending on the selection of IO 1...6

Function	IO 1	IO 2	IO 3	IO 4	IO 5	IO 6
Modbus RTU 120 Ω	RS485 A	RS485 B				
Modbus RTU	RS485 A	RS485 B				
Digital input (5...28V)	x	x				
Digital output (high-side switch – max. 20 mA)	x	x	x	x		
Current output (max. 700 Ω)			x	x	x	x

IO configuration\General

Parameter	Values	Default value
 «0/4mA...20 mA» Set current range for measured value output.	0...20 mA/4...20 mA	4...20 mA
 «For service» Set the measured value output in service mode.	0 Value/Last value	Last value
 «Max. value» Set the highest possible current value at the measured value output. Current values above 20.0 mA correspond to more than 100% measured value of the current measuring range.	20...21 mA	21 mA
 «If fault» Set the current value to be output in the event of an error (only relevant for current range 4...20 mA).	0...4 mA	2 mA
 «Name ext. in.» Assign a name to an external input signal (max. 7 characters).	...	External

	Parameter	Values	Default value
	«Prio. ext. inp.»	Off/Warning/Error/ Priority error	Warning
	Assign a priority to the external input signal.		

Modbus RTU 120Ohm/Modbus RTU

	«Function»	¹⁾ Off/Modbus RTU 120 Ω/Mod- bus RTU/digital input/digital output/ power output	Channel-specific
	Parameters are assigned to the functions and can be configured as required.		
	¹⁾ The Off function disables the function.		
	• Modbus RTU with 120 Ω (with matching resistor) • Modbus RTU (without matching resistor)		

	«Sigi-Link»	Off/On	Off
	Activate interface parameters for the connection to SICON/SiDis.		

	«Slave no.»	1...240	1
	Define the slave number with which the photometer is addressed in the control system.		

	«Baud rate»	4800/9600/19200/38400, 57600/115200/230400 baud	115200 baud
	Set the baud rate of the Modbus interface (baud rate in bits/s).		

	«Parity»	None/even/odd	Even
	Set the parity bits of the Modbus interface.		

	«Stop bit»	1/2	1
	Set the number of stop bits of the Modbus interface.		

Digital output (high-side switch – max. 20 mA)

	Parameter	Values	Default value
	«Digital output»	Inverse/prioritised error/error/warn- ing/service/calibration/sensor check/ humidity/limit value	Prioritised error/error/warning

When an event occurs, a signal is output to the correspondingly configured IO. If several functions are selected for an output, they are linked with a logical OR, i.e. the signal is output as soon as one of the events occurs.

Inverse: Invert function.

Prioritised error: Active when a prioritised error has occurred.

Fault: Active when a fault has occurred.

Warning: Active when a warning has occurred.

Service: Active when the device is in service mode.

Adjustment: Active when the device is performing an adjustment.

Sensor check: Active when a sensor check is in progress.

Humidity: Active if the humidity limit is exceeded.

Limit: Active when the limit is active. After activation, additional parameters are displayed for defining the limit (here [▶ 31](#))).

Digital input (5...28V)

	Parameter	Values	Default value
	«Digital input»	Inverse/operation serv./sensor check/external	-
	Input signal triggers the corresponding function. Inverse: Invert the functions. So that the function is triggered at signal 0. Operation/Serv.: Switching between measuring mode and service operation. Sensor check: Start sensor check. External: Activate external warning message.		

Power output terminal (max. 700 Ω)

	Parameter	Values	Default value
	«Source»	K1...Kn/M1...Mn/Humidity/Inactive	Inactive
	Available sources.		
	«Measuring range»	Device-specific	Device-specific
	From...To Values of the measuring range.		

Digital output\limit value (IO 1...4)

This function only appears if the limit value has been activated in the "Digital output" function.

	Parameter	Values	Default value
	«Source»	K1...Kn/M1...Mn/Humidity	-
	Available sources.		
	«Mode»	Inactive/exceeded/below	Inactive
	Set whether the limit value function is inactive or should react to undercutting or exceeding the limit value.		
	«Upper limit»	0...999999	1,000
	Set upper limit value.		
	«Lower limit»	0...999999	0,900
	Set lower limit value.		
	«Cut in delay»	0...60000	0 s
	Enter the cut-in delay for the respective limit value channel.		
	«Cut-out delay»	0...60000	0 s
	Enter the cut-out delay for the respective limit value channel.		

9.4.2 Menu: IO module EG_PoE

See communication module EG_PoE [▶ 25](#)

9.4.3 Menu: IO module EG_Profibus

See communication module EG_Profibus [▶ 26](#)

9.4.4 Menu: IO module EG_Profinet

See communication module EG_Profinet [▶ 26](#)

9.4.5 Menu: WLAN**WLAN\ General**

Parameter	Values	Default value
-----------	--------	---------------

**«WLAN region»**

List of regions

USA

Select the region in which the device is operated. WLAN channels 1...11 are used in the USA. Channels 1...13 are used in other countries

WLAN\ base station

Parameter	Values	Default value
-----------	--------	---------------

**«MAC address»**

F0:26:4C:XX:XX:XX

Device-specific

Displays the MAC address of the WLAN access point.

**«SSID»**

XXXXXX

Device-specific

Displays the SSID of the WLAN base station.

**«Deactivate after»**

...

300 s

If there is no active connection, the WLAN access point is deactivated after the set time.

**«Password»**

XXXXXX

Enter the password for the WLAN access point.

WLAN\ WLAN connection

Parameter	Values	Default value
-----------	--------	---------------

**«Active»**

On/Off

-

Switch WLAN connection on/off.

**«DHCP»**

On/Off

On

Automatic assignment of IP addresses.

- DHCP On: Assigned IP address, gateway address and subnet mask are displayed.
- DHCP Off: Enter IP address, gateway address, subnet mask and DNS server manually.

**«Set up»****[Start...]**

Device-specific

Select network and enter password. The connection may be interrupted and must be re-established.

**«Network ID (SSID)»**

XXXXXX

-

Display the ID (SSID) of the connected network.

**«MAC address»**

F0:26:4C:XX:XX:XX

Device-specific

Displays the MAC address of the WLAN connection.

**«IP address»**

XXX.XXX.XXX.XXX

192.254.1.1

Enter IP address.

	Parameter	Values	Default value
	«Gateway addr.» Enter gateway address.	XXX.XXX.XXX.XXX	192.255.255.0
	«Sub-net mask» Enter subnet mask.	XXX.XXX.XXX.XXX	255.255.255.0
	«DNS server» Enter DNS server address. Appears if DHCP is set to Off .	XXX.XXX.XXX.XXX	0.0.0.0

9.4.6 Menu Configuration

See Simple Configuration Model\ Configuration [▶ 24](#)

9.4.7 Menu: Display

Display\ General

	Parameter	Values	Default value
	«Values» Selection of the measured value display in the graphic display.	Min. value/Max. value/Average value	Mean value
	«For service» Value shown in the graphic display during service mode.	0 Value/Last value	Last value
	«Image rotation» Set the orientation of the display on the photometer.	0°/90°/180°/270°	0°
	«Display brightness» Set the brightness of the display on the photometer.	0...100 %	50%
	NOTICE! Low brightness reduces power consumption and extends the life of the display.		
	«Power-saving mode» Time period after which the display brightness on the photometer is reduced without manipulation.	0...65535 s	300 s
	«Standard display» If «Display idle symbol» is deactivated, the display switches to the standard display after 3 minutes of inactivity.	Values/1 hour/1 day/7 days/Sensor status	Sensor status

Display\ channel D1 ... Dn

	Parameter	Values	Default value
	«Source» Sequence of the measuring channels as they are to be shown in the display. The source refers to the channels defined in the «Meas. Channels» menus.	K1...Kn/ M1...Mn/Humidity/Inactive	Cn
	«Resolution» Set the number of decimal places after the decimal point to be used for displaying measured values.	1/1.2/1.23/1.234	1,234

	Parameter	Values	Default value
	«Min. auto» Activate automatic scaling of the graphic display to the minimum value.	On/Off	Off
	«Min. value» Set the minimum value of the graphic display when automatic scaling is switched off	0...999999	0,000
	«Max. auto» Activate automatic scaling of the graphic display to the maximum value.	On/Off	On
	«Max. value» Set the maximum value of the graphic display when automatic scaling is switched off.	0...999999	1,000

9.4.8 Menu: Simulation

See Simple parameterization mode/Menu: Simulation [▶ 26](#)

9.4.9 Menu: Recalibration

See Simple parameterization mode/Menu: Recalibration [▶ 27](#)

9.4.10 Menu: Sensor check

	Parameter	Values	Default value
	«Sensor check» The sensor check is an internal plausibility check of the photometer.	Start...	
	«Check interv.» Set the interval between two sensor checks. If the value is 0, the function is inactive. If the function is active, the first sensor check takes place one hour after the device is switched on.	0...10000	24 h (1 day)

9.4.11 Menu: Logger

	Parameter	Values	Default value
	«Interval» Set cycle of data storage to microSD card.	0 .. 60000 s	60 s
	«Dist. symbol» Set character between two columns.	Tab/ comma	Tab
	«End character» End of line character definition (Windows: CR + LF/ Mac: CR, Unix: LF).	CR + LF/ CR/ LF	CR + LF
	«SD card folder» Displays the contents of the SD card. Data can be downloaded and deleted.	Display ...	

Logger / Data

	Parameter	Values	Default value
	«Active» Activates the logger function and saves the measuring values.	On / Off	Off
	«Fault» Saves the error message.	On/Off	Off
	«Current value» Storage of the measured current.	On/Off	Off
	«Inner temp» Storage of photometer inner temperature.	On/Off	Off
	«LED-Temp» Storage of LED temperature.	On/ Off	Off
	«Humidity» Storage of humidity value.	On / Off	Off

9.4.12 Menu: System

	Parameter	Values	Default value
	«Mandatory operation» Time period after which the device automatically returns to measuring mode without manipulation (mandatory operation). This prevents the measuring device from remaining in service mode for any length of time and no relevant measured value/ limit value being output.	60 s...60000 s	900 s
	«Date format» Set the format of the date.	DD.MM.YYYY/ MM/DD/YYYY/ YYYY/MM/DD	DD.MM.YYYY
	«Summer time» Set daylight saving time. For Europe , daylight saving time is set on the last Sunday in March and winter time on the last Sunday in October.	No/Yes/ Europe	Europe
	«OTA update sends extended diagnostic data» During an online firmware update, operating hours, temperatures, voltages, light source intensities and the error history are transmitted.	On/Off	On
	«Contact information» Enter line 1 of the contact information (max. 47 characters).	...	Sigrist-Photometer AG
	«Contact information» Enter line 2 of the contact information (max. 47 characters).	...	Switzerland

	Parameter	Values	Default value
	«Contact information» Enter line 3 of the contact information (max. 47 characters).	...	+41 41 624 54 54
	«Contact information» Enter line 4 of the contact information (max. 47 characters).	...	info@sigrist.com

9.4.13 Menu: Meas. Channels

Meas. Channels\Channel K1...Kn

	Parameter	Values	Default value
	«Linearisation» Definition of a customer-specific linearisation with eight interpolation points (actual/target value pairs). Measured values are linearly interpolated between basic values. Measured values that are smaller than the smallest nominal basic value are treated as the smallest basic value. Measured values outside the highest nominal basic value are displayed as an overflow (****).	Define...	1100/1100 – 0.000/0.000
	«Offset» Offset value is added to the measured value.	-5000...999999	0,000
	«Scaling» Set the scaling factor for a customer-specific unit of measurement or for adaptation to laboratory values. The scaling factor is multiplied by the measuring value. The unit can be set separately, e.g. E = 1,000, EBC = 25,000, etc. with Set unit ▶ 36 .	Device-specific	-
	«Integration» Set the integration time for the forming of measured values. The integration is done via a low-pass filter. The set integration time corresponds to the step response of the measured value from 0...90 %.	0...60000 s	10 s
	«Designation» Enter the name to identify this channel (max. 7 characters).	...	Channel-specific
	«Unit» Set character string for a customer-specific unit (max. 7 characters).	...	-

9.4.14 Menu: Math. Channels

Math. Channels M1 ... Mn

	Parameter	Values	Default value
	«Function»	Inactive a*C1+... $10^{(a \cdot \log C1 + \dots)}$ C1/C2 $(C1 - C2) / C1$	Device-specific
	Selection of a predefined function for calculating different channels:		
	• $a \cdot K_1 + b \cdot K_2 + c \cdot K_3 + d \cdot K_4$ (Weighted addition of channels set to extinctions (log)) • $10^{(a \cdot \log(K_1) + b \cdot \log(K_2) + c \cdot \log(K_3) + d \cdot \log(K_4))}$ (Weighted addition of channels set to transmission (Lin)) • $\frac{K_1}{K_2}$ (Formation of quotients for second channels) • $\frac{K_1 - K_2}{K_1}$ (Difference of two channels in relation to the first channel)		
	«Offset»	-5000...999999	0,000
	Offset value is added to the measured value.		
	«Scaling»	-5000 ... 999999	1.000
	Set the scaling factor for adaptation to laboratory values. The scaling factor is multiplied by the measured value.		
	«Integration»	0...60000 s	10 s
	Set the integration time for the forming of measured values. The integration is done via a low-pass filter. The set integration time corresponds to the step response of the measured value from 0...90 %.		
	«Designation»	...	Device-specific
	Enter the designation to identify this channel (max. 7 characters).		
	«Unit»	...	
	Enter the unit (max. 7 characters).		
	«Coeff. a/b/c/d»	-5000 ... 999999	Device-specific
	Set the coefficient value a/b/c/d within the function.		

9.4.15 Menu: Measuring info

	Parameter	Values	Default value
	«Measurement info»	-	-
	View various values of the current measuring mode. Measured values K1...Kn/Math values M1...M2/indoor temperature/LED temperature/humidity value/+5 V analogue voltage/-10 V analogue voltage		

9.4.16 Menu: History


See Simple parameterization mode/Menu: History [▶ 27](#)

9.4.17 Menu: System info

See Simple parameterization mode/Menu: System info [▶ 28](#)

9.5 Logger diagram

Detailed graphic display of measured values over the last seven days.



Graphical display of measuring values (1)

Display over a certain period of time ((X): Time axis/ (Y:) measuring range). The curve colour corresponds to the corresponding measuring channel (7).

Time scales (2)

Define the time period from which the logger data is to be loaded (preview of data points under position (8))

- Large displayed range (1) corresponds to selected range under position (8).
- Date cursor: Date of the displayed measurement value (cursor position).
- Detail: Percentage of all displayed measurement points.
- Values: Determines whether the curves represent minimum, maximum or average values.

Cursor position (3)

Set time of measuring value display by mouse movement.

Export (TSV) (4)

Logger file is exported as .txt file.

Settings (5)

Set the measuring ranges per channel (drop-down menu). Changes are adopted for the graphic display on the unit.

Measured value display cursor position (6)

Measured value display refers to cursor position (3). The minimum (double arrow down), maximum (double arrow up) and average values are displayed.

Measuring value channels (7)

List of available measuring channels. Each channel can be activated or deactivated.

Time segment of measured value display (8)

Set the time segment of the measured value display (duration and time can be set).

9.6 Field bus

9.6.1 General requirements

- The computer or the control system must be compatible with the bus system Modbus RTU/TCP, Profibus DP or Profinet IO.
- The photometer must be equipped with the appropriate communication module.

9.6.2 Fault codes

The fault codes apply to all field bus versions. The fault description and corresponding measures can be found here [▶ 48](#).

No fault	Prioritised faults	Fault	Warnings
0: NO FAULTS	1: DEFAULT VALUES 3: CRC EXPERTS 4: CRC USER 5: CRC DISPLAY	8: SERIAL 1 16: U ANALOG 17: MEASURING FAULT 19: LIGHT SOURCE 1 20: LIGHT SOURCE 2	2: WATCHDOG 25: U ON 27: ADJUSTMENT 28: SENSOR CHECK 29: OVER.TEMP 30: HUMIDITY 33-40: CURRENT 1 ... 8 41: TEMP. SENSOR 43: EXTERNAL ON 53: IO_PORT 57: ABSORPTION TOO HIGH 78: SERVICE 82: BATTERY

EXTERNAL (43) can be configured by the user as a warning, fault or prioritised error.

9.6.3 Modbus RTU/TCP

9.6.3.1 Modbus RTU general

- The EG_IO module must be integrated.
- The Modbus RTU interface must be activated and parametrised in the menu «IO module EG_IO».

9.6.3.2 Modbus TCP general

- The EG_POE module or the EG_Profinet module with active transparent mode must be integrated. Alternatively, the Modbus TCP interface is available on the WLAN interfaces.
- The communication runs on port 502.
- Only one Modbus TCP connection may exist at the same time. An unused connection is terminated after 30 seconds.

9.6.3.3 Address table Modbus RTU/ TCP

NOTE



Malfunction due to writing data to undocumented addresses

Writing data to non-documented addresses can lead to the device becoming non-functional.

- Only documented addresses according to the module table may be used.

The following values can be read with Modbus function 4:

Register	Address	Data type	Function	Values
30001	0x0000	Unsigned integer bits 15-0	Status	Fault codes
30002	0x0001	Unsigned integer bits 15-0	Fault source	0: Local
30003	0x0002	Real 32-bit Intel single precision bits 15-0	Measured value channel 1	
30004	0x0003	Real 32-bit Intel single precision bits 31-16		

Register	Address	Data type	Function	Values
30005	0x0004	Real 32-bit Intel single precision bits 15-0	Measured value channel 2	
30006	0x0005	Real 32-bit Intel single precision bits 31-16		
30007	0x0006	Real 32-bit Intel single precision bits 15-0	Measured value channel 3	
30008	0x0007	Real 32-bit Intel single precision bits 31-16		
30009	0x0008	Real 32-bit Intel single precision bits 15-0	Measured value channel 4	
30010	0x0009	Real 32-bit Intel single precision bits 31-16		
30011	0x000A	Real 32-bit Intel single precision bits 15-0	Measured value channel 5	
30012	0x000B	Real 32-bit Intel single precision bits 31-16		
30013	0x000C	Real 32-bit Intel single precision bits 15-0	Measured value channel 6	
30014	0x000D	Real 32-bit Intel single precision bits 31-16		
30015	0x000E	Real 32-bit Intel single precision bits 15-0	Measured value channel 7	
30016	0x000F	Real 32-bit Intel single precision bits 31-16		
30017	0x0010	Real 32-bit Intel single precision bits 15-0	Measured value channel 8	
30018	0x0011	Real 32-bit Intel single precision bits 31-16		
30019	0x0012	Real 32-bit Intel single precision bits 15-0	Math channel 1	
30020	0x0013	Real 32-bit Intel single precision bits 31-16		
30021	0x0014	Real 32-bit Intel single precision bits 15-0	Math channel 2	
30022	0x0015	Real 32-bit Intel single precision bits 31-16		

9.6.4 Profibus-DP

- The EG_Profibus module must be integrated. This supports the DP-V1 standard.
- The connection to the Profibus master must be established.
- If the device is used as an end device, the bus must be correctly terminated.
- The slave number must be set in the "EG_Profibus IO module" menu.
- The correct GSD file (SIG11D4.gsd) must be loaded in the Profibus master, the required modules must be plugged in and the associated variables must be defined.

9.6.5 Profinet-IO

- The EG_Profinet module must be integrated. This supports conformance class B.
- The connection to the Profinet master must be established.
- The interface parameters must be set in the «**EG_Profinet communication module**» menu. Alternatively, these can be set using a Profinet parameterization tool.
- The correct GSDML file (GSDML-V2.44-Sigrist-Photometer AG-EG_Profinet-20240621.xml) must be loaded in the Profinet master, the required modules must be plugged in and the associated variables must be defined.
- If «**Profinet transparent mode**» is active, the device's web server can be accessed. If the mode is inactive, the web server of the gateway module (HMS) can be accessed for diagnostic purposes.

9.6.6 Profibus-DP/Profinet-IO data

The data is divided into 15 input and 3 output modules. Only the first two modules are required for the basic functionality. The individual modules can be omitted and assigned to any slots.

The implementation is identical for all Sigrist devices. Depending on the device type, not all data is used.

Module table

Module name	Data type	Byte size	In/Out	Description	Min.	Max.
Status	byte	1	In	Bit 7: Live Bit 0-6: Fault codes		
	Byte	1	In	Limit status 1...8		
Meas. values 1...2	2xReal	8	In	Meas. values 1...2		
Meas. values 3...4	2xReal	8	In	Meas. values 3...4		
Meas. values 5...8	4xReal	16	In	Meas. values 5...8		
Meas. values 9...16	8xReal	32	In	Meas. values 9...16		
Meas. values 17...24	8xReal	32	In	Meas. values 17...24		
Status 1...2	2xByte	2	In	Status of measuring value 1...2		
Status 3...4	2xByte	2	In	Status of measuring value 3...4		
Status 5...8	4xByte	4	In	Status of measuring value 5...8		
Status 9...16	8xByte	8	In	Status of measuring value 9...16		
Status 17...24	8xByte	8	In	Status of measuring value 17...24		
Diagnosis	SIInt	1	In	Humidity		
	SIInt	1	In	Electronics temperature		
	SIInt	1	In	Heater temperature		
	SIInt	1	In	Soiling		
Control In	Byte	1	In	Live inverse		
	Byte	1	In	Operating mode		
Control In	Byte	1	In	Start (LabScat)		
	Byte	1	In	Lin table (LabScat)		
Config In	Byte	1	In	Integration 1...8		

Module name	Data type	Byte size	In/Out	Description	Min.	Max.
	Byte	1	In	Heater set point		
	Byte	1	In	Heater max. value		
	Byte	1	In	LV1...4 Cut-in delay		
	Byte	1	In	LV1...4 Cut-out delay		
	Byte	1	In	LV5...8 Cut-in delay		
	Byte	1	In	LV5...8 Cut-out delay		
	Byte	1	In	GW hysteresis *)		
Config Limits In	8xReal	32	In	Limit value 1...8		
Config Limits In	Real	4	In	Scaling 1		
	Real	4	In	Flow rate GW		
	Real	4	In	Soiling GW		
Control Out	Byte	1	Out	Live inverse	0	255
	Byte	1	Out	Operating mode	0	4
Control Out	Byte	1	Out	Start (LabScat)	0	2
	Byte	1	Out	Lin table (LabScat)	0	7
Config Out	Byte	1	Out	Integration 1...8	0	255
Config Out	Byte	1	Out	Heater set point	0	100
	Byte	1	Out	Heater max. value	0	75
	Byte	1	Out	LV1...4 Cut-in delay	0	255
	Byte	1	Out	LV1...4 Cut-out delay	0	255
	Byte	1	Out	LV5...8 Cut-in delay	0	255
	Byte	1	Out	LV5...8 Cut-out delay	0	255
	Byte	1	Out	GW hysteresis*)	0	100
Config Limits Out	8xReal	32	Out	Limit value 1...8	-5000	1.00E+09
Config Limits Out	Real	4	Out	Scaling 1	0.1	10
	Real	4	Out	Flow rate GW	-10	20000
	Real	4	Out	Soiling GW	0001	1000

*) Limit hysteresis: Lower limit value = upper limit value * (100.0 - value)/100

All available measuring values (meas. channels, math channels, analogue channels) are output in sequence under "Meas. values 1...n".

When writing, all values must be within the permissible limits, otherwise all changes will be discarded.

Communication monitoring:

There are two options for monitoring communication. On the one hand, a live bit (module: status – bit 7), which alternates between 0 and 1 every second. If this is used, an adequate evaluation logic is required.

The second option is an inverse byte. A value can be written to the corresponding address (module: Control Out – live inverse), after a time of max. 3...5 s the value is output inverted (module: Control In – live inverse). Write access to the photometer must be permitted for this function. This can be enabled via the menu "IO module EG_Profi/Control -> External".

10 Servicing

⚠ CAUTION

Unit damage due to lack of maintenance



Lack of or inadequate maintenance as well as the use of non-original Sigrist spare parts may damage the device and lead to measurement errors.

- ▶ Always carry out servicing work according to the servicing schedule.
- ▶ Only use original Sigrist spare parts.
- ▶ In case of high strain or rough environmental influences, shorten servicing intervals and replace wear parts more frequently.

10.1 Maintenance schedule

The maintenance interval must be adjusted according to the environmental conditions.

Recommendation:

When	What	Action	Who
Annual/ "Humidity" warning	Desiccant	Replace	Operator
Annual	Sensor head	Cleaning	Operator
	Manual adjustment	Check calibration	Operator
	VARINLINE® housing seals	Replace	Operator

10.2 Replace desiccant

NOTE



Condensation inside the electronics


When the sample medium is cold, humidity can condense when the unit is opened and damage the electronics.

- ▶ Only open the photometer when the medium temperature is $\geq$ room temperature.



If the desiccant is changed frequently, have the seal checked by a service technician.

- ▶ Remove cover (2) with tool (3).
- ▶ Replace desiccant (1).
- ▶ Mount cover (2) immediately.



10.3 Cleaning

The appliance is designed for CIP (Cleaning in Place) and does not need to be removed for cleaning in the system.


- ▶ Do not use aggressive cleaning agents or chemicals that may affect the contact surface of the material with the product.
- ▶ For applications outside the food industry, the cleaning interval must be adapted to the medium.

10.3.1 Clean sensor head

WARNING!

Do not remove the photometer without first draining the process line!

- ▶ Remove the photometer.
- ▶ Clean windows (1), (2), (3) with mild, abrasive-free cleaning agent (e.g. alcohol or soap). Use a soft, non-lint cloth.
- ▶ Install the photometer.



10.4 Calibration check

DANGER

Skin or eye damage due to formazine (hydrazine sulphate).


Unprotected skin or eye contact with formazine may cause skin or eye damage.

- ▶ Wear protective goggles and gloves.
- ▶ Wash hands after work.



10.4.1 Overview of control unit

- (1) TurBiScat PM 40
- (2) Clamp ring
- (3) VARINLINE® adapter
- (4) Fill level indicator
- (5) Filling funnel stand
- (6) Filling funnel



Overview control unit

10.4.2 Cleaning the control unit

NOTE

Cleaning the control unit



Unsuitable cleaning agents can cause damage to the solid body.

- ▶ Clean the inside and outside of the control unit with a soft, lint-free cloth. In case of heavy soiling, a mild, abrasive-free cleaning agent can be used (e.g. alcohol).
- ▶ Put the protection cover on the control unit and store it in the case.
- ▶ The control unit must be stored away from soiling, humidity, frost and temperatures above +80 °C.

10.4.3 Carry out calibration check with control unit

NOTE



Use of an incorrect control unit.

Using the wrong control unit can falsify the calibration check.

- ▶ The number of the control unit must match the serial number of the device.

Removing the photometer

WARNING!

Do not remove the photometer without first draining the process line!

- ▶ Removing the photometer


Establishing the WLAN connection

- ▶ Establish WLAN connection with mobile device.
- ▶ Place the device on a soft and flat surface with the sensor head pointing upwards. Avoid using a metal plate as a base (WLAN connection interruption).

Remove solid reference from the control unit


When testing with formazine (K1, K2) and zero adjustment (K3, K4), remove the solid reference from the control unit (general calibration check).

- ▶ Loosen two screws (1).
- ▶ Remove the solid reference (2) from the control unit.




Fit the control unit

- ▶ Align the bolt (1) with cut-out (2).
- ▶ Fit the control unit.



Fastening the control unit (VARINLINE® connector)


- ▶ Attach the control unit (1) to the photometer with clamp ring (2).



Filling the control unit

- ▶ Fill the control unit (1) with test medium via the filling funnel (3).
- ▶ Ensure that the fill level indicator (2) is filled to approx. halfway.

Bubble formation can be prevented by slowly filling the control unit. Remaining bubbles can escape by swaying the device back and forth or by quickly squeezing the sample tube.



Carry out calibration check

- ▶ Open menu Settings/«Recalibration».
- ▶ Select the channel to be calibrated.
- ▶ Check or enter the set point.
 - Recalibrate the control unit with solid reference (K1, K2): «Set point» must match the one on the control unit.
 - Recalibration with formazine (K1, K2): Enter the value of the formazine solution in the «Set point» menu.
 - Zero point adjustment (K3, K4) with ultrapure water: Enter value 0 in the «Set point» menu.
- ▶ Press [Trigger].
 - ⇒ The calibration check is started.
 - ⇒ Calibration check successful OK.
- ▶ Repeat the procedure for each channel.

Calibration check not OK (recalibration fault)

- ▶ Check for correct mounting of the control unit.
- ▶ Check for window soiling on the sensor head.
- ▶ Check the test medium for air bubbles.


- ▶ Check the set points.
- ▶ Trigger the calibration check again.



If the calibration check is not successful, contact your local representative.

Complete the calibration check

- ▶ Empty the control unit and remove it from the photometer.
- ▶ Install the photometer.
- ▶ Put the photometer into operation.
- ▶ Align the solid reference (1) on bolts (2) and fasten it.
- ▶ Clean the control unit [▶ 45].
 - ▷ The calibration check is completed.




10.5 Replace seals (VARINLINE® connection)

WARNING!

Do not remove the photometer without first draining the process line!

- ▶ Remove photometer (1) and sealing plate (3).
- ▶ Replace seal (2) on the sensor head.
- ▶ Replace seal (4) on sealing plate (3).
- ▶ Fit photometer (1) and sealing plate (3).



10.6 Spare parts

Spare parts are available online.

<https://www.sigrist.com/Turbidity-Meters-Analyzers-Liquid/TurBiScat-PM-40/Parts>



11 Troubleshooting

11.1 Isolate faults

Malfunction	Measure
No display	▶ Check service voltage.
Error message in display	▶ Analyse error message (Warning/error/priority messages).
Measured value seems wrong	▶ Ensure correct operating conditions of the sample medium. ▶ Check calibration. ▶ Check correct mounting. ▶ Ensure that servicing duty has been carried out correctly. ▶ Perform sensor check.

11.2 Warning/(Prio) error messages

In the event of a malfunction, either the measurement monitor with error message (1) or a corresponding status signal (2) is displayed, depending on the setting.

With a swipe movement, the detailed information appears.

Warning messages

- System remains in operation.
- Evaluate measurement results with caution.
- The warning disappears after the cause has been rectified.

► Call up QR code (5).

► Rectify cause promptly.


(1) Warning message with measured value display

(2) Warning status symbol

(3) Warning code

(4) Warning message

(5) QR code



(Prio) error messages

- Measured values are set to 0.
- Operation is impossible.

► Call up QR code (5).

► Rectify the cause immediately.

(1) Error message with measured value display

(2) Status symbol (prio) error


(3) Fault code

(4) Error message

(5) QR code

NOTICE!

Prioritised errors must be cleared by a service engineer.



11.3 Warning messages

The following warning messages may be displayed during operation.

Code	Message	Cause	Remedy
W2	WATCHDOG	• Internal fault monitoring triggered • Programme has been restarted	• Ensure stable 24 V supply • Exclude EMC influences • Defective electronics • Contact service engineer
W25	U ON	Input voltage is outside the permissible range (24 VDC)	• Check input voltage

Code	Message	Cause	Remedy
W27	RECALIBRATION	• Device is soiled • Set point for recalibration does not match the value of the medium	• Clean measuring cell and control unit if necessary • Check control unit/medium • Check set point • Check light path
W28	SENSOR CHECK	Automatic sensor check failed	• Too much external light near the measuring cell (e.g. sight glass) • Device open • Defective optics/electronics • Contact a service technician
W29	OVERTEMP	Temperature in the device has exceeded 69 °C	• Check medium and ambient temperature and adjust if necessary • Repair or install cooling system
W30	HUMIDITY	Relative humidity in the device above the set limit value	• Replace desiccant • Replace housing seal • Localise leaks and rectify defect
W33 ... W40	CURRENT 1...8	Current output is disturbed	• Open connection terminals • Interruption in the current loop of the measured value output • Contact service engineer
W41	TEMP.SENSOR	Inner temperature sensor has failed	• Defective electronics • Contact service engineer
W43	EXTERNAL ON	An external event is signalled via a digital input	• Analyse external fault • Check cabling
W53	IO_PORT	Communication interruption to touch screen	• Defective electronics • Contact service engineer
W57	ABSORPTION TOO HIGH	Light beam blocked, medium too dark or foam	• Check light path and rectify defect
W78	SERVICE	Indicates when maintenance is due	• Contact service engineer
W82	BATTERY	Battery level too low	• Set date and time • Replacing the battery

11.4 Fault messages

The following fault messages may be displayed during operation.

Code	Message	Cause	Remedy
E8	SERIAL 1	Communication interruption between main controller and sensor board	• Defective electronics • Contact service engineer
E16	U ANALOG	One of the internal analogue voltages is outside the permissible range	• Defective electronics • Contact service engineer
E17	MEASURING FAULT	Measurement value acquisition is disturbed	• Instrument not in process line • Air bubbles present in the medium • Extraneous light near the measuring point (e.g. sight glass) • Defective electronics • Contact service engineer
E19	LIGHT SOURCE 1	Detector for monitoring the light source is not receiving light from the corresponding light source.	• Defective light source • Contact service engineer

Code	Message	Cause	Remedy
E20	LIGHT SOURCE 2	Detector for monitoring the light source is not receiving light from the corresponding light source.	Defective light source Contact service technician.

11.5 Prio fault messages

The following prio error messages may be displayed during operation.

Code	Message	Cause	Remedy
P1	DEFAULT VALUES	Default values have been loaded	Defective electronics Contact service technician
P3	CRC EXPERTS	An error was detected during the check of the expert data.	Defective electronics Contact service engineer
P4	CRC USER	An error was detected when checking the user data	Defective electronics Contact service engineer
P5	CRC DISPLAY	An error was detected when checking the display data	Defective electronics Contact service engineer

12 Specification sheet

12.1 TurBiScat PM 40

Service voltage

24 VDC $\pm$ 10 % (EG_PoE 48 VDC)

Warm-up time

< 3 min

Power input

Max. 4 W

Max. pressure

- Max. 4 MPa (40 bar) → Sensor head with sapphire window
- Measuring cell → Observe specification, standard Varinline housing 1 MPa (10 bar)

Medium temperature

- -10 ... +100 °C
- 120 °C max. 2 h
- 150 °C max. 1 h

Ambient temperature

- -10 ... +50 °C
- +55 °C → max. medium temperature +85 °C
- +60 °C → max. medium temperature +75 °C

Ambient humidity

0 ... 100 % relative humidity

Material

- Housing: Stainless steel 1.4301 / AISI 304
- Touchscreen: Soda-lime tempering glass

Parts in contact with medium:

- Sensor head: Stainless steel 1.4404 / AISI 316L
- Window: Sapphire
- VARINLINE® housing: Stainless steel 1.4404 / AISI 316L

Dimensions

Ø 100.5 x 128 mm

Tube connections

DN 40 ... DN 150, 1 1/2" ... 6" VARINLINE® housing

Weight

Approx. 2.3 kg

Protection class

IP 66

Certification

EHEDG EL Class I

Display (model -S1XX only)

- Display: 2.4" with touchscreen
- Resolution: 320 x 240 pixels

Cleaning

CIP/SIP-compatible up to 150 °C

WLAN module (model -S1XX only)

WLAN according to IEEE 802.11 b/g/n

12.2 General

Turbidity measurement

Measuring principle

90°/25° scattered light measurement

Wavelength

650 nm

Measuring range

0 ... 1000 EBC (0 ... 4000 NTU) turbidity

Measuring ranges

Arbitrarily configurable

Lowest measuring value

20 mEBC

Smallest recommended measuring range

0 ... 1 EBC

Resolution

0.001 EBC turbidity

Reproducibility

2 devices calibrated with the same formazine

EBC

90°

25°

0 ... 2	± 1 %	± 1 %
2 ... 100	± 2 %	± 3 %
100 ... 1000	± 10 %	± 10 %

Linearity

0.01 EBC turbidity in the range 0 ... 2 EBC

Repeatability (2 measurements with 1 device)

0.001 EBC turbidity or ± 0.25 % of the measuring value

Temperature stability

$< -0.15 \text{ \%}^{\text{K}^{-1}}$ of upper limit of the range

Reaction time

< 2 s (step response)

Colour measurement (optional)

Measuring principle

Absorption

Wavelength

430 nm

Measuring range

0 ... 50 EBC colour (fixed layer)

Smallest measuring range

0 ... 5 EBC colour

Reproducibility

± 0.3 EBC colour

Repeatability

± 0.2 EBC colour

12.3 SiDis AD 40

Service voltage

24 VDC $\pm$ 10 % (EG_PoE according to standard)

Power input with photometer

Max. 4 W

Display

- Display: 1/4 VGA with touchscreen
- Resolution: 320 x 240 pixels with 2.4" diagonal

WLAN module

WLAN according to IEEE 802.11 b/g/n

Protection class

IP 66

Weight

Approx. 0.4 kg

Dimensions

Ø 105.5 x 71 mm

Material

- Housing: PC/ABS UL94 V0
- Touchscreen: Soda-lime tempering glass

12.4 Communication modules

EG_IO

6 configurable inputs/outputs:

- Max. 2 digital inputs: 5 ... 28 VDC
- Max. 4 digital outputs: High-side switch max. 20 mA
- Max. 4 power output terminals: 0/4 ... 20 mA, max. 700 ohm
- Modbus RTU

EG_PoE

Ethernet LAN connection with Power over Ethernet:

- Ethernet according to 10/100BaseT
- PoE according to 802.3af, class 0

EG_Profibus

Profibus DP-V1 slave

EG_Profinet

Profinet IO, conformity class B

13 Returns

Returns to the appropriate country representative

For all devices and spare parts that are returned, a completed RMA form must be sent to the responsible Sigrist-Photometer AG country representative (RMA form 14711D can be downloaded from www.sigrist.com).

DANGER

Residues of hazardous media

Depending on the area of application, a dismantled device may contain residues of hazardous media. These residues can endanger persons.



- ▶ Thoroughly clean all surfaces that come into contact with the media.
- ▶ Remove all aggressive, toxic or hazardous substances in or on the device, as well as on the associated peripheral devices.
- ▶ Note the decontamination process on the RMA form and have it confirmed.

Use the original packaging when returning the photometer. If this is not available, observe the following instructions.

- ▶ Empty the device completely and dry it.
- ▶ Before packaging, seal the openings of the device with tape or pins so that no parts of the packaging units can penetrate inside.
- ▶ The device contains optical and electronic components. Ensure with the packaging that no impact can affect the device during transport.
- ▶ Pack all peripheral devices and accessory parts separately and label them with the serial number of the photometer. This prevents later confusion and facilitates the identification of the parts.
- ▶ Enclose the completed RMA form and mark the RMA number on the outside of the packaging.
 - ▷ Packaged in this way, the devices can be transported using all standard freight routes.

14 Decommissioning/storage

Prepare components for storage

The aim of decommissioning is to prepare the individual components of the unit properly for storage.

- ▶ Disconnect the operating voltage.
- ▶ Dismantling the photometer.
- ▶ Clean sensor head.
- ▶ Check desiccant and replace if necessary.
- ▶ Ensure that all openings on the device are sealed.

Storing the components

Ensure that the following conditions are met for storage:

The components contain electronic parts. Storage must meet the usual conditions for such components. In particular, ensure that the storage temperature is in the range -20 ... +60 °C.

All components that come into contact with the medium during operation must be dry and clean for long-term storage.

All components must be protected from the effects of weather, condensing humidity and aggressive gases during storage.

15 Disposal

The components must be disposed of in accordance with regional legal regulations. The components do not have any radiation sources that are harmful to the environment. The materials used must be disposed of or reused in accordance with the following table:

Category	Materials	Disposal option
Packaging	Cardboard, paper	Reuse as packaging material, local disposal points, incineration plants
	Protective films, polystyrene shells	Reuse as packaging material, recycling
Electronics	Printed circuit boards, electro-mechanical components, display and cables	To be disposed of as electronic waste
Optics	Glass, plastic and stainless steel	Recycling via used glass and scrap metal collection points
Battery	Lithium	Recycling via locally organised collection points
Photometer housing	Stainless steel	Scrap metal collection points
Desiccant	Molecular sieve	Normal waste disposal (chemically harmless)

Your service partner

Sigrist-Photometer AG

Hofurlistrasse 1
CH-6373 Ennetbürgen

Tel. +41 (0)41 624 54 54

www.sigrist.com
info@sigrist.com